

Commode Rail Lowering Bracket and Rail Installation

Refer to the drawing below to see how the commode lowering brackets with rails are attached to the chair frame.

- 1.) Slide the lowering bracket under the screw heads with the key-hole slot feature on the lowering brackets. Then tighten with your 5/32" Allen wrench and do the other side. Note, the lowering brackets and rails can be installed either with the pan sliding front to back as pictured below or side to side.
- 2.) Once installed the lips on the commode pan will slide between the grooves on the commode rails.

